



International Space Station Environmental Control and Life Support

Monsi Roman
NASA/Marshall Space Flight Center



Agenda

- **Environmental Control and Life Support Systems-
What is it?**
- **What kind of waste are we designing for?**
- **ISS Urine Processor**
- **ISS Water Processor**
- **Overview Challenges**
- **The Future**
- **Back-up Charts**

NASA/ M. Roman

2



ECLSS- What is it?

Control Atmosphere Pressure	Condition Atmosphere	Respond to Emergency Conditions	Control Internal CO ₂ & Contaminants	Provide Water	Prepare for EVA Operations
<ul style="list-style-type: none"> • O₂/N₂ Pressure Control Assemblies (USO/RS) • Positive & Negative Pressure Relief (USOS-Transport) • O₂/N₂ Storage (USOS, RS, Progress) • O₂ Generation Assembly, O₂ Solid Chemicals (RS) • Major Constituent Analyzer (USOS) (Share) • Gas Analyzer (RS) (Shared) 	<ul style="list-style-type: none"> • Cabin Air Temperature & Humidity Control Assemblies (All) • Ventilation Fans (USOS, RS, MPLM) • Air Particulate Filters (All) • Intermodule Ventilation Fans & Valves (All) • Ducting (All) 	<ul style="list-style-type: none"> • Smoke Detectors (All) • Portable Fire Extinguishers (All) • Fire Indicators and Fire Suppression Ports (All) • Portable Breathing Apparatus and Masks (All) • O₂/N₂ Pressure Control Assemblies (USOS) (Shared) 	<ul style="list-style-type: none"> • CO₂ Removal Assembly (USOS/RS) • CO₂ Vent (USOS/RS) • Trace Contaminant Control Assembly (USOS/RS) • Major Constituent Analyzer (USOS) • CO₂ Reduction Assembly (RS) • CO₂ LIOH Removal (RS) • Manual Sampling Equipment (USOS) • Gas Analyzer (RS) 	<ul style="list-style-type: none"> • Potable Water Processor (USOS/RS) • Urine Processor (USOS/RS) • Process Control Water Quality Monitor (USOS) • Condensate Storage (USOS/RS) • Fuel Cell Water Storage (USOS) • Waste Water Distribution (USOS) • Hygiene Water Processor (RS) 	<ul style="list-style-type: none"> • O₂/N₂ Pressure Control Assemblies (USOS) • O₂/N₂ Distribution (USOS) • O₂/N₂ Storage (USOS) • Major Constituent Analyzer (USOS) (Shared)
Atmosphere Control & Supply (ACS) & AR	Temperature Humidity Control	Fire Detection & Suppression & ACS	Atmosphere Revitalization (AR)	Water Recovery & Mgmt/ Waste Mgmt	ACS & AR

NASA/ M. Roman



THE ECLS CHALLENGE

Needs

Oxygen = 0.84 kg (1.84 lb)

Food Solids = 0.62 kg (1.36 lb)

Water in Food = 1.15 kg (2.54 lb)

Food Prep Water = 0.76 kg (1.67 lb)

Drink = 1.62 kg (3.56 lb)

Metabolized Water = 0.35 kg (0.76 lb)

Hand/Face Wash Water = 4.09 kg (9.00 lb)

Shower Water = 2.73 kg (6.00 lb)

Urinal Flush = 0.49 kg (1.09 lb)

Clothes Wash Water = 12.50 kg (27.50 lb)

Dish Wash Water = 5.45 kg (12.00 lb)

Total = 30.60 kg (67.32 lb)



Effluents

Carbon Dioxide = 1.00 kg (2.20 lb)

Respiration & Perspiration
Water = 2.28 kg (5.02 lb)

Food Preparation,
Latent Water = 0.036 kg (0.08 lb)

Urine = 1.50 kg (3.31 lb)

Urine Flush Water = 0.50 kg (1.09 lb)

Feces Water = 0.091 kg (0.20 lb)


Sweat Solids = 0.018 kg (0.04 lb)

Urine Solids = 0.059 kg (0.13 lb)

Feces Solids = 0.032 kg (0.07 lb)

Hygiene Water = 12.58 kg (27.68 lb)

Clothes Wash Water
Liquid = 11.90 kg (26.17 lb)
Latent = 0.60 kg (1.33 lb)
Total = 30.60 kg (67.32 lb)




NASA/ M. Roman

5

5-35327-2




The Life Support Loop





The Goal: Closing the Loop




NASA/ M. Roman

7



Regenerative ECLSS Racks



(H) = Hamilton Sundstrand provided hardware
(M) = MSFC provided hardware
Hamilton Sundstrand responsible for rack analytic integration for WRS#1
MSFC responsible for rack analytic integration for WRS#2 & OGS racks, physical integration for all 3.




Urine Processor Description

■ Integrated Process


- » Ambient temperature, low pressure distillation
- » Pretreated urine temporarily stored prior to processing






- » Purge pump periodically vent gases which accumulate in Distillation Assembly
- » Membrane phase separator recovers water from purged gases
- » Brine concentrated & ultimately removed in recycle filter tank





ISS Water Processor Description







Biofilm Challenges in Space

Wetted Materials in space life support systems include:

- » Titanium
- » 316L Stainless Steel
- » Teflon
- » Viton O-rings
- » Nickel-Brazed Stainless Steel

NASA/ M. Roman

12



ECLS Challenges

- **Urine/water (potable/wastewater) Hardware Health/Performance**
 - » Design life (10 years or more)
 - » Triple containment
 - » Control of biofilm and corrosion/MIC on wetted surfaces
 - Conditions in flight hardware difficult to assess
 - » Control of fungal growth in pretreated urine
 - » Separating steam from liquid/ gas from liquid
 - » Flow rates: low, intermittent or no flow
 - » Dead-legs
 - » Potential long term storage of water in Teflon bags
 - » Limitations with the use of antimicrobials
 - » What to do with the by-products/waste

NASA/ M. Roman

13



ECLS Challenges (cont.)

- **Urine/water (potable/wastewater)**
 - » Gravity/microgravity effects
 - pumps/valves
 - Back-contamination
 - » Wastewater in narrow tubes
 - » Storage/Holding time (between sample and analysis)
 - » Control of microorganisms in potable water
 - Re-growth potential/resistance to antimicrobials
 - MIC



ECLS Challenges





ECLS Challenges



NASA/ M. Roman


16




Space Station Oxygen Generator

- Core Technology: Solid Polymer Electrolysis (cathode feed)

Cell Stack



Electrolysis Cell Reactions






Oxygen Generator Description

■ Integrated Process

- » Oxygen & hydrogen produced in 28-cell stack
- » O₂ delivered to cabin
- » H₂ mixed with excess re-circulated water, separated dynamically, and vented overboard (ISS baseline)
- » Makeup water periodically added and stored within rotary separator
- » Oxygen lines purged with nitrogen for safety after shutdowns






Space Station Atmosphere Revitalization

TRACE CONTAMINANT
CONTROL SUBASSEMBLY

CO₂ REMOVAL
ASSEMBLY

MAJOR
CONSTITUENT
ANALYZER





CARBON BED



Microbial Challenges in Space

■ Challenges with monitoring in-flight include:

- » Viable vs non-viable microorganisms
- » Analysis of planktonic microorganisms vs. biofilm
- » Limited amount of samples
- » Expendables (waste generation)
- » Consumables (reusable is preferred)
- » Low power consumption
- » Equipment size
- » Non-hazardous reagents
- » Non-generation of hazardous waste
- » Calibration (positive/negative controls?)
- » Cleaning/disinfection of the sample collection areas
- » Maintenance/repairs
- » Upgrade as needed

NASA/ M. Roman

21



NASA/ M. Roman

22